


Operating Instructions (continued)

- 5** Place your right hand on the top of the blade carriage. Applying moderate pressure, slide the blade carriage down the entire length of the paper to cut.



- 6** Lift the paper clamp handle to remove the paper.



CAUTION:

Blades are very sharp! Keep hands and fingers away from the cutting edge at all times. Keep out of the reach of children.

For More info

Click Here ---->



Customer Service

Telephone: (260) 563-0641
Fax: (260) 563-4575
Email: info@martinyale.com
Internet: www.martinyale.com
Address: Martin Yale Industries, Inc.
251 Wedcor Avenue
Wabash, IN 46992

Visit www.martinyale.com for information on office products, including folding machines, punches, and catalog racks.


Premier[®]

HR120 12" Rotary Trimmer




Key Features and Benefits

- Paper clamp mechanism holds paper in place for accurate and safe cutting.
- Precise lighted cutting line assists accurate cutting
- Permanent grid and dual rulers for proper paper alignment. The angular grid makes tough angle cuts simple.
- Durable, adjustable paper stop maintains proper position of paper during clamping
- Cuts up to 20 sheets of 20# bond paper at a time.
- Non-skid feet




Key Components

- A – Trimmer Base
- B – Paper Stop
- C – Blade Carriage
- D – Paper Clamp Handle
- E – Cutting Light Switch



2 AAA Batteries Included



Assembly Instructions

Insert batteries into the bottom of the trimmer as shown.

Operating Instructions

- 1 Place the trimmer on a flat, stable surface. Turn on the light by pressing the cutting light switch near the paper clamp handle, if desired.




For More info

Click Here --->



- 2 Loosen the paper stop knob and slide the paper stop in the channel to the desired position using the rulers as a guide. Retighten.



- 3 Make sure the paper clamp handle is in its upward-most position and slide the paper beneath the clamp. Align the left edge of the paper with the paper stop.



- 4 Holding the paper in place with your left hand, use your right hand to press down firmly on the paper clamp handle.

